

Downloadable Fun

Personalize your phone with downloadable games, graphics and ringtones. Rogers gives you access to the latest games and graphics right on your phone and access to the best new ringtones from today's hottest artists. Personalize your phone today!


- From the Standby screen, press the LEFT SOFT key, Menu.
- Select 5. Rogers Mall.
- Choose from 1. Search, 2. Music and Tones, 3. Games, or 4. Graphics and press OK.
- When your web connection is established, choose a category and press OK.



Multimedia Messaging

Snap it. Say it. Multimedia Messaging lets you share photos, voice messages and more!

- From the Standby screen, press the LEFT SOFT key, Menu.
- Scroll to and select 2. Messaging.
- Select 1. Write New, followed by 2. Multimedia Messaging and press OK.
- Press the RIGHT SOFT key, Add, to add text, images, or sounds.
- After adding text, images, or sounds, press OK. Select a recipient and press the RIGHT SOFT key, Send.



Accessories

Rogers has accessories for productivity, convenience and fashion. You can also shop accessories at www.shoprogers.com



1 America Online, AOL, and the AOL logo are registered trademarks of America Online, Inc. in the United States and other countries. Other AOL product and service names are also trademarks of America Online, which may be registered in some countries. Yahoo!, Yahoo! Messenger, and the Yahoo! Logo are the owned intellectual property of Yahoo! Inc. Microsoft, MSN, and the MSN logo are either registered trademarks or trademarks of Microsoft Corporation in the United States and/or other countries.



- VGA Camera ::
- Instant Messaging (IM) ::
- International Services ::
- Downloadable Fun ::
- Multimedia Messaging ::

PANTECH | It's different



C3 Quick Start Guide

Use your phone for more than just talking

Getting to Know Your Phone



- 1 Internal Screen
- 2 Send Key
- 3 End/Power On/Off
- 4 Navigation Key
- 5 Left/Right Soft Keys
- 6 Clear/Back Key
- 7 Earpiece
- 8 Microphone
- 9 Volume Keys
- 10 Camera
- 11 Flash LED
- 12 External Screen

Changeable Covers

Make a personal statement with your mobile phone. With the C3, you can express yourself with a broad variety of colorful changeable covers.

- To remove cover, turn the phone upside down and use your thumbs to push the cover up in the direction of the arrows.



- To replace the cover, insert the ridges on each side of the cover into the slots on the phone. Press upwards in the direction of the arrows and snap into place.



Take a Picture

Capture those special moments right from your phone and send them to friends and family.

- From the Standby screen, press up on the NAVIGATION key to activate the camera.
- Press OK in the center of the NAVIGATION key to take a picture.
- Press the CLEAR/BACK key to return to the camera preview screen.



World's Smallest

Introducing the C3 from Pantech...the world's smallest camera flip phone. This pocket-sized companion is lightweight and stylish. Its slim design fits anywhere and the advanced technology found inside makes the C3 a truly outstanding phone.

